



REPAIR AND MAINTENANCE

Chain and Rear Tire Replacement


Tools required: Phillips screwdriver, 10mm wrench, two (2) 8mm wrenches, and two (2) 17mm wrenches.




1 With a Phillips screwdriver, remove the screws that secure the chainguard. Remove chainguard.




2 With a 10mm wrench, loosen the brake cable anchor and disconnect the cable.




3 With two 8mm wrenches, loosen brake housing anchor and disconnect. Keep the spacer and washers together.




4 With two 17mm wrenches, loosen the axle. Push the wheel forward in the slots to loosen the chain.




5 Pull the wheel out. Note the arrangement of the hardware sequence.
Note: Your hands will get greasy doing this.



6 Install the new chain or wheel by slipping the chain around the axle. Slide the axle into the slots on the frame. Slide the wheel forward and maneuver the chain onto the rear sprocket, front sprocket and chain tensioner.



7 Tighten the brake housing anchor securely.



8 Re-attach the chain guard. Test ride and check. Readjust as needed.